





Mounting & Service Manual Pro Signage

Philip Payne


MOUNTING



- 1** (1) Screw in the cable gland.
(2) Mount the mountingbox. **ATTENTION!** Place the screw caps on the chosen screw holes!



- 2** (1) Connect the wiring according to the wiring diagram.
(2) Tighten the cable gland.




- 3** (1) Write the installation on the battery label.
(2) Put the battery connector in position.




- 4** Click the reflector in the mountingbox.

WALL




- 5a** Insert the pictogram and press it into place as shown above.

WIRING DIAGRAM



SPECTO XT




DALI

CEILING



- 5b** Fold the pictograms as shown above. Position them together in the light cover.

CEILING



- 5c** Insert the blinding sheet and press it into place as shown above.

- 6** Place the light cover on the mounting box. Tighten the two SW3 socket head screws.


TESTING

STATUS INDICATION:

- Normal / Battery is being charged
- Required autonomy not achieved
- Battery failure
- Led signage failure
- Led escape route failure
- Elektronik failure

ATS CYCLE:

Automatic
Test
System




SERVICE




- 1** Monthly and annual tests should be carried out in accordance with BS EN 50172:2004, 7.2. Clean the luminaire every year with a damp cloth without cleaning liquids.



- 2** Loosen both SW3 socket head screws. Remove the light cover.



- 3** Remove the reflector from the mounting box. Use, optional, a screwdriver on the marked positions.



- 4** Change the battery if required autonomy isn't achieved. Write the date of service on the label of the new installed battery. Replace the gaskets.



Pro signage wall




Pro signage ceiling

SPECIFICATION

| Type | Voltage | Power consumption* | Current* | Power factor |
|-------------------|---------------|--------------------|----------|--------------|
| WALL DALI | 230 V / 50 Hz | 2 W | 20 mA | 0,5 |
| WALL SPECTO XT | 230 V / 50 Hz | 2 W | 20 mA | 0,5 |
| CEILING DALI | 230 V / 50 Hz | 2 W | 20 mA | 0,5 |
| CEILING SPECTO XT | 230 V / 50 Hz | 2 W | 20 mA | 0,5 |

*maximum values at switched-on light source and not fully charged battery



| | |
|-------------------|----------------------------------------------------------------------|
| Mounting | Installation on normal flammable surfaces |
| Temperature range | 0°C till +35°C, occasionally -20°C till +35°C |
| Dimensions | See www.philippayne.co.uk |
| Autonomy | 3 hours |
| Light source | LED |
| Testsystem | Automatic Test System (IEC 62034) |
| Battery | 3,6 V 1,1 Ah NiMH |
| Protection rate | IP65, IP66 and IK10 |
| Insulation class | Class II, double insulated (no ground connection needed) |
| Material | PC - ABS |

Warranty, accessories and spacing tables and further information see www.philippayne.co.uk.